

1. Pair WPP with Touch Panel

Pair WPP20 with MTouch II


Connect WPP20 to the USB port of MTouch II for pairing, and wait for more than 3 seconds until the WPP20 LED indicator turns solid green.



Accessories

Last Update Time: 2023-07-18 Pageviews: 4012 https://support.yealink.com/en/portal/knowledge/show?id=64b64c2c5b323b55e7a98572

- AVHub Installation
- MCore Installation
- MCore Pro Installation
- MCore Lite Installation
- MTouch E2 Installation
- MTouch Plus Installation
- MSpeech Installation
- MVC BYOD-Extender Installation
- RCH40 Installation
- USB Connector Installation
- BYOD Box Installation
- USB Extender Installation
- SmartVision 60 Installation
- MTouchPlus-EXT Installation



Why does the Yealink wireless screen transmitter software prompt a failure to connect to the host?

Last Update Time: 2022-11-11 Pageviews: 751

- 1. check that the RoomCast host is turned on as a wireless hotspot.
- 2. Plug the WPP20/30 into the RoomCast and re-pair it.
- 3. Replace the WPP20/30 or computer and try again.